

# Retainer Rings

1.



2.



3.



4.



6.



7.



## Half-mast instructions

1.



- Remove the screw and let the swivel ring slide down.
- After the swivel ring is slid down – you will screw the threaded topper back in place so the ball doesn't blow off your flagpole.

2.



- Extend the top section of your flagpole so that the button locks in place.
- The swivel ring will rest on the top of the second section. Take the bolt provided in the package and use a 15/32" socket wrench and tighten the bolt against the tube. As you tighten the bolt, the screws will cut its own threads into the ring.

3.



- Attach the top of the flag to the ball bearing ring and the bottom to the beaded retainer ring. Extend the remaining sections of the flagpole.